

The protocol of switch input source on PRO controller

1#select SDI source

Request command:

55 aa 00 2b fe 00 00 00 00 00 01 00 22 00 20 02 01 00 1a de 56

2#select DVI source

Request command:

55 aa 00 34 fe 00 00 00 00 00 01 00 22 00 20 02 01 00 1c e9 56

3#select HDMI source

Request command:

55 aa 00 3f fe 00 00 00 00 00 01 00 22 00 20 02 01 00 1b f3 56

4#select VGA source

Request command:

55 aa 00 48 fe 00 00 00 00 00 01 00 22 00 20 02 01 00 17 f8 56

5#select DP source

Request command:

55 aa 00 51 fe 00 00 00 00 00 01 00 22 00 20 02 01 00 1e 08 57

6#select CVBS source

Request command:

55 aa 00 5a fe 00 00 00 00 00 01 00 22 00 20 02 01 00 02 f5 56